

Figure 2

A-S Correlation 231

# Figure 3

SEMANTIC

CONTROL ON DEVICE 66

C-S Correlation 221

				402		<u>`</u>		_		
SEMANTIC	STEER	ACCELERATE	DECELERATE	SHIFT UP	FIRE	DASHBOARD	RUMBLE	•	•	•
ACTION IN APPLICATION 36a	tum left or right	dn peeds	slow down	change to next higher gear	fire machine guns	change dash display	feedback	•	•	•
				7	/					

302

ACCELERATE

Right Pedal

STEER

Steering Wheel

SHIFT UP

Button 1

FIRE

Trigger 1

DECELERATE


Left Pedal

RUMBLE

Vibrate

TALK

**Button 2** 










Figure 6












MAPPER API 1006



# Figure 11




assistr assistant




Information						
elect a control with the mouse,	☐ Sort Assigned					
y moving an axis or by pressing button.	Home - Start/pause	P				
spation.	F1 - Change weapons	Q				
	C - Shoot	R				
	`F	s				
Player	A	T				
<b>A</b>	B	U				
Game Mode	D	V				
▼	er same same	M				
Available Actions	G'	X				
Turn	. H	Y				
Moye	I	Z				
Start/pause	J =	0				
Change weapons	K	7-				
Sol	M -	3-				
Change View	M	3				
Change Ship/Type	0 -	5 -				
	9	·	₩.			
The state of the s						


### **ENUMDEVICES BYSEMANTICS**




### **CONFIGDEVICES**



### BUILDACTIONMAP



## **SETACTIONMAP**



### GETIMAGEINFO

